



OPERATING & MAINTENANCE INSTRUCTIONS

To ensure years of trouble free use from your Easifold 3000 doors it is recommended that you read and fully understand the operating instructions as follows:-

OPENING THE DOORS

1. Insert the key into the lead door and turn anti clockwise through 360° to release the deadbolt in the multipoint lock. Operate the door handle in a downward motion to release the multipoint locking system and door latch. Open the lead door fully through 180° and ensure that the magnetic door stays are holding the door fully open. (This will help the doors glide more easily)
2. Release the shoot bolts on the slave doors by turning the shoot bolt lever through 90° and leave in this position. Push the doors away from you (if the doors open out of the room) or pull the doors towards you (if the doors open into the room) to start the folding operation.
3. At the hinge side of the lead door, guide the doors along the track system until they are fully open. (Repeat steps 2 and 3 as necessary if you have more than 3 doors in one direction).

CLOSING THE DOORS

1. Guide the lead door at the hinge side along the track (Do not use the lead door handle to drag the doors along the track as it will cause the doors to operate in an accordion type motion and restrict the effectiveness of the running gear.) Keep the lead door located on the magnetic door stays.
2. Use the "D" – handle above the shoot bolt lever to pull the doors closed. Turn the shoot bolt lever in a downward motion through 90° to locate the shoot bolts into the track. (Do not use the shoot bolt lever to pull the doors closed. No warranty claim will be accepted in respect of this)
3. Use the lead door handle pull the door closed until it latches then lift the handle upwards to engage the multipoint lock and turn the key clockwise through 360° to engage the deadbolt in the multipoint lock.

CARE & MAINTENANCE

Maintenance

Your Easifold 3000 door system contains mechanical moving parts that will need to be lubricated bi – annually these include; hinges; multipoint lock; handles. Lubricate using a light oil or spray oil and wipe away any excess with a non abrasive cloth once you have finished. The "Freeglide" running system in your Easifold 3000 door system is maintenance free and will not require lubrication.

Care of your Easifold 3000 door system

1. Powdercoated aluminium profile – use a light soapy solution and a non abrasive cloth to wipe dirt from the doors. DO NOT USE an abrasive cloth such as a scouring pad as the Easifold 3000 door system has a painted finish and can be scratched. It is NOT recommended that you use solvent based cleaning products; care must be taken if you intend to use such products.
2. "TPE" gaskets – use a light soapy solution and a non abrasive cloth. DO NOT USE solvent based cleaning products on the gaskets. It is recommended that silicon spray is applied to the gaskets annually.
3. Tracks – use a small brush to loosen any debris from the track. Using a suitable vacuum cleaner with a thin nozzle cleaning attachment. Vacuum up the debris in the track. (This should be carried out on a weekly basis) DO NOT allow debris to build in the track as this will effect the operation of the doors.

THIS LEAFLET MUST BE HANDED TO THE END USER OF THE EASIFOLD 3000 DOOR SYSTEM